

## Insta-Check pH Pencil



#149-P-13N

- **Hydriion pH Pencils** are available as **JUMBO**, non-refillable, paper wrap pencils, lead size 3/16" \* 6.75"
- **Hydriion INSTA-CHEK pH PENCILS** has readings from **pH 0 to 13** with **fourteen brilliant - easy to read - color changes**.
- It will reveal the surface pH of any solid to the nearest unit pH value.

### Used for:

- Paper
- Paperboard
- Lumber
- Concrete
- Cement
- Plaster • Plasterboard
- Canvas & Tarpaulins
- Pre-Paint Surfaces
- Finished Surfaces
- Metals
- Solder Joints
- Textiles • Synthetic Fibers
- Felts
- Skin & Hides
- Leather
- Batteries • Plastics
- Photo Films & Papers
- Resin Treated Materials
- Ceramics & Pottery

### HOW TO USE THE pH Pencil

First wet the surface or area with distilled water. Then stroke surface several times with the pH pencil. After thirty seconds, compare the resulting color with the color chart. The markings must be wet with distilled water to obtain the correct color. The color produced is stable and will persist for a long time.

Distributed in Canada by:  
**QPC Instruments Inc.**