

Protimeter Aquant Plus 2 Moisture Detector for Boats&Yachts



The Protimeter Aquant Plus 2 has the unique facility for detecting moisture levels both at depth and at near surface layers in the hull material.

This facility is invaluable for the early detection of excessive moisture in GRP structures. In turn, this is important when assessing the potential for, or the extent of OSMOSIS and for monitoring the drying rate of the hull prior to treatment.



There are **two modes** of testing:

In-depth readings for moisture trapped inside the laminate.

Near-surface readings using the especially designed **Filed Concentrator Attachment**.

Features of the Protimeter Aquant Plus 2 include:

Simple easy to use, with one hand operation

An adjustable audible tone.

A relative scale of 16 LEDs, with a 5 second memory on the last recorded value.

Specifications

Power 1 x 9v

Range 101 to 115 Relative Clip on Field Enhancer (reduces depth of detection)

Carry Pouch

Order #118-BLD5756