

HOLD*BLAST™

HOLD*BLAST prevents flash rust for days and days...



HOLD*BLAST
is an all organic surface
passivator
and soluble salt remover.

#136-HOLD*BLAST- 5+ 55+ 160+ 320+ 480+ 800+ 960+
\$ per gallon Ask about our quantity discounts***

1 gallon containers are shipped 4 per carton / add \$3.30 per gallon for packaging
5 gallon containers are shipped 32 per pallet
55 gallon drums are shipped 4 per pallet

Wet abrasive blasting?—Just add it to the water

Use a 1:50 to 1:250 dilution, depending on water quality, contamination and environmental considerations.

Dry blasting?—Do a quick pressure wash afterwards

With most potable water use a 1:50 dilution—dilute it even further when using quality water.

Need to reduce salts?—Let HOLD*BLAST go to work for you

Meet specifications requiring a reduction in salts. HOLD*BLAST removes chlorides, sulfates and even nitrates, the most problematic salts commonly found.

Cost considerations?—HOLD*BLAST is affordable!

‘Hold the blast’ and remove salts economically—it costs only pennies per square foot.

Adhesion concerns?—Not a problem!

This product does not leave a residue that interferes with coating adhesion. HOLD*BLAST simply passivates and removes salts.

**Use HOLD*BLAST on your next project
to prevent flash rust and remove salts!**

HOLD*BLAST™ Surface Passivator and Soluble Salt Remover

Data Sheet

BENEFIT: As a surface passivator, HOLD*BLAST chemically changes the active surface of metal to a much less reactive state. Surface corrosion can occur when water wet surfaces react with atmospheric oxygen. This often results in the formation of flash rust, which can be eliminated with the use of HOLD*BLAST. This product passivates the surface to stop the formation of surface rust for long periods of time, often several days.

DESCRIPTION: HOLD*BLAST is a concentrated organic chemistry which is added to water. This biodegradable product does not leave a film or residue to interfere with coating adhesion. HOLD*BLAST also solubilizes and removes salts during surface passivation.

USES: HOLD*BLAST is a cost effective, environmentally safe, coating friendly additive to prevent flash rusting and to remove soluble salts.

Use in a solution with water:

after:

- * dry abrasive blasting
- * power tool cleaning
- * UHP WaterJetting

or during:

- * water washing
- * wet abrasive blasting
- * slurry blasting

SURFACE PREPARATION: Many specifications require no flash rust and/or reduced soluble salts. This product will help meet that specification.

APPLICATION: Application methods vary.

EQUIPMENT CLEANUP: Flush with clean fresh water.

It is not necessary to use entire contents. Partially filled containers should be closed tightly.

Color: Colorless Single component

Shelf life: 36 months pH 10.8 (+/- 0.2)

Application temperature: 35 to 211F Packaging: 5/55 gallon

Solubility: Complete Phosphates: NONE

Non-flammable Biodegradable

Storage: Out of direct sunlight, avoid freezing Non-hazardous

Odor: Slight pleasant odor No VOC's

WARRANTEE: CHLOR*RID International Inc. warrants this product to be identical in chemical and physical properties from batch to batch within the specification limits of the raw materials used in their manufacture.

SAFETY PRECAUTIONS: KEEP OUT OF REACH OF CHILDREN. Do not mix with other chemicals.