

## Plastic Shims

For use with magnetic, eddy-current and ultrasonic coating thickness gauges. Not intended for use with magnetic pull-off type gauges.

Each Set consists of (5) color-coded shims and is supplied in a sturdy envelope. *(One set is included with each PosiTector coating thickness gauge)*



They provide a quick operational check of the probe by allowing the user to perform practice measurements. They can also be used to protect the probe when measuring on tacky, rough or hot surfaces. Some Test Methods and Specifications call for their use when making calibration adjustments.

**Order # 200-038**

While these shims are inspected to the Stated Tolerance, they are not traceable to any national or international standards.

### Plastic Shim Specifications

Microns	Mils	Accuracy (±)	Color	Couleur	Farbe
25.4	1	20%	Amber	Ambre	Bernstein
50.8	2	10%	Red	Rouge	Rot
127	5	5%	Blue	Bleu	Blau
254	10	5%	Brown	Brun	Braun
508	20	5%	Yellow	Jaune	Gelb

Distributed in Canada by:  
**QPC Instruments Inc.**