

## Series 137-UK

UKK Compression Force Gauge  
UKT Tension Force Gauge



### UK Ranges (Resolution UKT & UKK Models)

Pounds	
Model*	Capacity (Resolution)
UK-5	5 lb. (0.05 lb.)
UK-10	10 lb. (0.1 lb.)
UK-20	20 lb. (0.2 lb.)
UK-30	30 lb. (0.25 lb.)
UK-50	50 lb. (0.5 lb.)

Kilograms	
Model*	Capacity (Resolution)
UK-2 kg	2 kg (20 g)
UK-3 kg	3 kg (25 g)
UK-5 kg	5 kg (50 g)
UK-10 kg	10 kg (100 g)
UK-20 kg	20 kg (200 g)
UK-30 kg	30 kg (250 g)

- Dimensions: 4<sup>1</sup>/<sub>2</sub>" L x 2<sup>1</sup>/<sub>2</sub>" W x 2" D
- Ideal for OEM or permanent installation
- Can be used in tight spaces where other gauges will not fit
- Specially designed dial will retain peak values

The UK series mechanical force gauges are dedicated compression only or tension only instruments for use in confined spaces, or for permanent installation into a piece of equipment or machinery. The specially designed dial will retain peak values while simultaneously displaying real time measurements. The threaded shaft will accept any of the standard FB/PS replacement measuring attachments. Dedicated compression and tension ranges are available for your specific needs. Newton gauges are available.