

137-LH-220 Manual Lever Test Stand



Force gauge sold separately

LH-220 without distance meter

LH-220S with distance meter

- **Tension and compression testing**
- **Horizontal positioning is easy to control**
- **Lever action allows for rapid testing**
- **Large work area accommodates a wide variety of samples**
- **Stroke 4"**
- **Maximum load 220 lbs. (100 kg)**

The LH-220 Horizontal Manual Lever Test Stand provides maximum versatility and reliability. The stand will accommodate any of the standard range Imada force gauges. The large working platform accommodates a wide variety of samples—ideal for peel test measurements. The stand is unaffected by gravity and does not employ a return spring, making it perfect for crimp testing and other applications where rapid sample loading is desirable. The lever action provides for quick, consistent tests. Threaded feet enable the test stand to be easily leveled. The LH-220S model is equipped with a digital distance meter.

Distance Meter Specifications

Display	Push button for inch/mm, zero set and on/off
Resolution	0.0005"/0.01 mm
Accuracy	0.1% of reading or 0.005"/0.1mm, whichever is greater
Stroke	2"