

Kestrel® Interface

The Kestrel® Interface is the ideal companion to the Kestrel 4000 Pocket Weather Tracker. With the optional computer interface, data can be uploaded for long-term storage, in-depth analysis and detailed charting. Simply connect the interface cable to the serial port on your PC, rest the Kestrel 4000 on the cradle, and upload your stored data. The included software is easy to use and saves the data in a comma delimited text file for use in your choice of applications: text editor, spreadsheet or database.



Order #105-0830

Computer Requirements

Compatibility PC
 Connectivity Serial Port (Com 1-4)
 Operating System Windows 3.1 or Higher
 Memory 4MB
 Hard Disk Space 1.4MB

Sample Screen Shot

Kestrel® Pocket Weather Tracker - Upload Application V1.6											
File 20020425A.CSV File Created: 04/25/2002 at 15:33:50 Size 3,386 bytes											
FORMATTED DATE-TIME	DT	WS	TP	WC	RH	HI	DP	WB	BP	AL	DA
YYYY-MM-DD-HH:MM:SS	s	mph	@F	@F	%	@F	@F	@F	inHg	ft	ft
2002-04-25-15:36:02	73064162	0.0	78.8	78.8	41.5	78.4	53.6	64.0	29.83	28	1566
2002-04-25-15:36:09	73064169	0.7	80.2	80.2	41.0	80.0	54.1	64.7	29.83	27	1648
2002-04-25-15:36:11	73064171	0.0	82.7	82.7	55.2	85.6	64.7	70.7	29.82	33	1883
2002-04-25-15:36:14	73064174	0.0	87.4	87.4	72.6	101.3	77.5	80.0	29.83	32	2343
2002-04-25-15:36:18	73064178	0.0	84.0	84.0	76.7	93.7	75.9	77.9	29.82	34	2105
2002-04-25-15:36:21	73064181	0.0	82.4	82.4	74.5	89.9	73.5	75.9	29.83	26	1953
2002-04-25-15:36:32	73064192	0.0	80.6	80.6	62.6	83.8	66.7	71.0	29.82	36	1789
2002-04-25-15:36:34	73064194	0.0	80.7	80.7	60.8	83.8	65.8	70.7	29.82	38	1801
2002-04-25-15:36:36	73064196	0.0	80.7	80.7	59.0	83.4	64.9	70.1	29.82	38	1768
2002-04-25-15:36:38	73064198	0.0	80.6	80.6	57.9	83.1	64.2	69.6	29.82	40	1760
2002-04-25-15:36:40	73064200	0.8	80.4	80.4	54.1	82.2	62.0	68.5	29.80	53	1760
2002-04-25-15:36:42	73064202	0.7	80.2	80.2	51.4	81.5	60.2	67.4	29.82	37	1698
2002-04-25-15:36:44	73064204	0.0	80.0	80.0	50.2	81.1	59.5	67.1	29.81	47	1698
2002-04-25-15:36:46	73064206	0.0	79.8	79.8	48.7	80.7	58.8	66.7	29.81	43	1678
2002-04-25-15:36:48	73064208	0.0	79.7	79.7	47.7	80.4	58.1	66.3	29.82	38	1669
2002-04-25-15:36:50	73064210	0.0	79.7	79.7	46.8	80.2	57.5	66.0	29.82	36	1657
2002-04-25-15:36:52	73064212	0.0	79.5	79.5	45.8	79.8	56.8	65.6	29.82	35	1616
2002-04-25-15:36:54	73064214	0.0	79.5	79.5	44.9	79.7	56.1	65.3	29.82	34	1616
2002-04-25-15:36:56	73064216	0.0	79.3	79.3	44.2	79.1	55.4	64.9	29.82	34	1607
2002-04-25-15:36:58	73064218	0.0	79.1	79.1	43.5	78.9	55.2	64.7	29.82	33	1587
2002-04-25-15:37:00	73064220	0.0	79.1	79.1	42.9	78.8	54.5	64.5	29.82	33	1587
2002-04-25-15:37:02	73064222	0.0	79.1	79.1	42.4	78.8	53.9	64.4	29.82	33	1587
2002-04-25-15:37:04	73064224	0.0	78.9	78.9	41.9	78.6	53.7	64.2	29.82	33	1575
2002-04-25-15:37:06	73064226	0.0	78.9	78.9	41.4	78.4	53.0	63.8	29.82	33	1575

Distributed in Canada by:
QPC Instruments Inc.